



i62



ascom

www.ascom.us | 877-71ASCOM | PL-000044r1


i62



ascom

www.ascom.us | 877-71ASCOM | PL-000044r1


i62



ascom

www.ascom.us | 877-71ASCOM | PL-000044r1


i62



ascom

www.ascom.us | 877-71ASCOM | PL-000044r1

Power On/Off, End Call/Function

Press Power/End key  to end call or function. Power on/off with long press Power/End key, press “Yes”.

Answer Call & Send

Press Send key .

Make & Send Call

Dial number. Press Send key or “Call”.

OR... Use Call List to redial: Press Send key. Press “Call” to redial the selected number.

Mute Ringer

Long press “Mute” button while handset is idle. Music note with line thru indicates muted handset. *Note: pressing “Mute” during call will mute your speech to the 2nd party.*

Hold / Retrieve

Press “More”. Scroll to “Hold”. Press “Select”. Press “Retrieve” to get call back.

Transfer


After 2 handsets are connected, press “Trans” (2nd party on hold). Dial number of 3rd party then press the send key.

Handset typically configured to mimic wired desk phones e.g. 9 for outside line etc.

ascom

www.ascom.us | 877-71ASCOM | PL-000044r1

Power On/Off, End Call/Function

Press Power/End key  to end call or function. Power on/off with long press Power/End key, press “Yes”.

Answer Call & Send

Press Send key .

Make & Send Call

Dial number. Press Send key or “Call”.

OR... Use Call List to redial: Press Send key. Press “Call” to redial the selected number.

Mute Ringer

Long press “Mute” button while handset is idle. Music note with line thru indicates muted handset. *Note: pressing “Mute” during call will mute your speech to the 2nd party.*

Hold / Retrieve

Press “More”. Scroll to “Hold”. Press “Select”. Press “Retrieve” to get call back.

Transfer

After 2 handsets are connected, press “Trans” (2nd party on hold). Dial number of 3rd party then press the send key.

Handset typically configured to mimic wired desk phones e.g. 9 for outside line etc.

ascom

www.ascom.us | 877-71ASCOM | PL-000044r1

Call Waiting

Beeps indicate 2nd incoming call, press “Accept”. Scroll and press “End” to disconnect from selected phone number.



Loudspeaker

Press “Loudspeaker Icon ” during a call.


Send Text Messages

Press “Menu”. Scroll to “Messaging” “Select”. Scroll to “Write New Message” “Select” and write message. Press “Send”. Enter handset number. Press “Send”. *Note: Space is 0 key. Press Star key to toggle between upper/lower case and digits.*

Find Stored Text Messages

Press Up scroll arrow () **OR...** Press “Menu”. Scroll to “Messaging ”. Scroll to “Inbox” “Select”.

Lock/Unlock Handset


Press Star key () , press “Lock/Unlock” option shown on screen.

Handset typically configured to mimic wired desk phones e.g. 9 for outside line etc.

ascom

www.ascom.us | 877-71ASCOM | PL-000044r1

Power On/Off, End Call/Function

Press Power/End key  to end call or function. Power on/off with long press Power/End key, press “Yes”.

Answer Call & Send

Press Send key .

Make & Send Call

Dial number. Press Send key or “Call”.

OR... Use Call List to redial: Press Send key. Press “Call” to redial the selected number.

Mute Ringer

Long press “Mute” button while handset is idle. Music note with line thru indicates muted handset. *Note: pressing “Mute” during call will mute your speech to the 2nd party.*

Hold / Retrieve

Press “More”. Scroll to “Hold”. Press “Select”. Press “Retrieve” to get call back.

Transfer


After 2 handsets are connected, press “Trans” (2nd party on hold). Dial number of 3rd party then press the send key.

Handset typically configured to mimic wired desk phones e.g. 9 for outside line etc.

ascom

www.ascom.us | 877-71ASCOM | PL-000044r1

Power On/Off, End Call/Function

Press Power/End key  to end call or function. Power on/off with long press Power/End key, press “Yes”.

Answer Call & Send

Press Send key .

Make & Send Call

Dial number. Press Send key or “Call”.

OR... Use Call List to redial: Press Send key. Press “Call” to redial the selected number.

Mute Ringer

Long press “Mute” button while handset is idle. Music note with line thru indicates muted handset. *Note: pressing “Mute” during call will mute your speech to the 2nd party.*

Hold / Retrieve

Press “More”. Scroll to “Hold”. Press “Select”. Press “Retrieve” to get call back.

Transfer

After 2 handsets are connected, press “Trans” (2nd party on hold). Dial number of 3rd party then press the send key.

Handset typically configured to mimic wired desk phones e.g. 9 for outside line etc.

ascom

www.ascom.us | 877-71ASCOM | PL-000044r1

Call Waiting

Beeps indicate 2nd incoming call, press “Accept”. Scroll and press “End” to disconnect from selected phone number.



Loudspeaker

Press “Loudspeaker Icon ” during a call.


Send Text Messages

Press “Menu”. Scroll to “Messaging” “Select”. Scroll to “Write New Message” “Select” and write message. Press “Send”. Enter handset number. Press “Send”. *Note: Space is 0 key. Press Star key to toggle between upper/lower case and digits.*

Find Stored Text Messages

Press Up scroll arrow () **OR...** Press “Menu”. Scroll to “Messaging ”. Scroll to “Inbox” “Select”.

Lock/Unlock Handset

Press Star key () , press “Lock/Unlock” option shown on screen.

Handset typically configured to mimic wired desk phones e.g. 9 for outside line etc.

ascom

www.ascom.us | 877-71ASCOM | PL-000044r1